Clear Interior Finish Touch Up Field Applied Instruction



ABSTRACT: This instruction demonstrates how to repair small imperfections. For procedures on repairing larger areas, contact your local Marvin representative.



WARNING

Follow all safety, hazard, cleanup, and disposal instructions from the manufacturer of any product used to fill holes, dents, and minor imperfections as well as touch up materials.

Supplies Needed

Tack cloth Hair dryer (optional)
Paper towels for cleanup 200-400 grit sand paper
.75 ounce bottle of clear interior finish with applicator (part number 11401918)

1. Sand area lightly with 200-400 grit sandpaper to feather out edges of existing coating.

Clean area properly with a tack cloth. Apply clear interior finish to the surface of the area with applicator. Multiple light coats may be necessary. See figure 1.



Figure 1



Tip

To accelerate drying, use a hair dryer on low setting.