



# 1 3/4" ULTIMATE SWINGING FRENCH DOOR TRANSOMS

1 FRAME 4 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad MO (mm)</b>	7-11 1/2 (2426)	9-11 1/2 (3035)	10-7 1/2 (3239)	11-11 1/2 (3645)	13-11 1/2 (4255)
<b>Wood MO (mm)</b>	8-2 1/8 (2492)	10-2 1/8 (3102)	10-10 1/8 (3305)	12-2 1/8 (3712)	14-2 1/8 (4321)
<b>RO (mm)</b>	8-0 (2438)	10-0 (3048)	10-8 (3251)	12-0 (3658)	14-0 (4267)
<b>FS (mm)</b>	7-11 (2413)	9-11 (3023)	10-7 (3226)	11-11 (3632)	13-11 (4242)
<b>DLO (mm)</b>	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)

1-6 1/4 (464)  
 1-8 1/4 (514)  
 1-6 1/2 (470)  
 1-6 (457)  
 0-9 5/16 (237)



8016  
 8020  
 8026



10016  
 10020  
 10026



10816  
 10820  
 10826



12016  
 12020  
 12026



14016  
 14020  
 14026