












1 3/4" ULTIMATE SWINGING FRENCH DOOR TRANSOMS

1 FRAME 1 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

Clad MO (mm)	1-8 11/32 (517)	2-1 15/16 (659)	2-7 15/16 (811)	2-9 15/16 (862)	3-1 15/16 (964)	3-7 15/16 (1116)	4-1 1/8 (1248)
Wood MO (mm)	1-10 31/32 (583)	2-4 9/16 (725)	2-10 9/16 (878)	3-0 9/16 (929)	3-4 9/16 (1030)	3-10 9/16 (1183)	4-3 3/4 (1314)
RO (mm)	1-8 27/32 (529)	2-2 7/16 (672)	2-8 7/16 (824)	2-10 7/16 (875)	3-2 7/16 (976)	3-8 7/16 (1129)	4-1 5/8 (1260)
FS (mm)	1-7 27/32 (504)	2-1 7/16 (646)	2-7 7/16 (799)	2-9 7/16 (849)	3-1 7/16 (951)	3-7 7/16 (1103)	4-0 5/8 (1235)
DLO (mm)	0-11 1/2 (292)	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)	3-0 25/32 (934)






1-6 1/4 (464)							
1-8 1/4 (514)	1616	2016	2616	2816	3016	3616	4016
1-6 1/2 (470)	1620	2020	2620	2820	3020	3620	4020
1-6 (457)	1626	2026	2626	2826	3026	3626	4026
0-9 5/16 (237)							

Clad MO (mm)	5-1 1/8 (1553)	5-5 1/8 (1654)	6-1 1/8 (1857)	7-1 1/8 (2162)
Wood MO (mm)	5-3 3/4 (1619)	5-7 3/4 (1721)	6-3 3/4 (1924)	7-3 3/4 (2229)
RO (mm)	5-1 5/8 (1565)	5-5 5/8 (1667)	6-1 5/8 (1870)	7-1 5/8 (2175)
FS (mm)	5-0 5/8 (1540)	5-4 5/8 (1641)	6-0 5/8 (1845)	7-0 5/8 (2149)
DLO (mm)	4-0 25/32 (1239)	4-4 25/32 (1341)	5-0 25/32 (1544)	6-0 25/32 (1849)

1-6 1/4 (464)				
1-8 1/4 (514)	5016	5416	6016	7016
1-6 1/2 (470)	5020	5420	6020	7020
1-6 (457)	5026	5426	6026	7026
0-9 5/16 (237)				






1 FRAME 2 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

Clad MO (mm)	4-1 1/8 (1248)	5-1 1/8 (1553)	5-5 1/8 (1654)	6-1 1/8 (1857)	7-1 1/8 (2162)
Wood MO (mm)	4-3 3/4 (1314)	5-3 3/4 (1619)	5-7 3/4 (1721)	6-3 3/4 (1924)	7-3 3/4 (2229)
RO (mm)	4-1 5/8 (1260)	5-1 5/8 (1565)	5-5 5/8 (1667)	6-1 5/8 (1870)	7-1 5/8 (2175)
FS (mm)	4-0 5/8 (1235)	5-0 5/8 (1540)	5-4 5/8 (1641)	6-0 5/8 (1845)	7-0 5/8 (2149)
DLO (mm)	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)

1-6 1/4 (464)					
1-8 1/4 (514)	4016	5016	5416	6016	7016
1-6 1/2 (470)	4020	5020	5420	6020	7020
1-6 (457)	4026	5026	5426	6026	7026
0-9 5/16 (237)					

1 FRAME 3 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

Clad MO (mm)	6-0 5/16 (1837)	7-6 5/16 (2294)	8-0 5/16 (2446)	9-0 5/16 (2751)	10-6 5/16 (3208)
Wood MO (mm)	6-2 15/16 (1903)	7-8 15/16 (2361)	8-2 15/16 (2513)	9-2 15/16 (2818)	10-8 15/16 (3275)
RO (mm)	6-0 13/16 (1849)	7-6 13/16 (2307)	8-0 13/16 (2459)	9-0 13/16 (2764)	10-6 13/16 (3221)
FS (mm)	5-11 13/16 (1824)	7-5 13/16 (2281)	7-11 13/16 (2434)	8-11 13/16 (2738)	10-5 13/16 (3196)
DLO (mm)	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)

1-6 1/4 (464)					
1-8 1/4 (514)	6016	7616	8016	9016	10616
1-6 1/2 (470)	6020	7620	8020	9020	10620
1-6 (457)	6026	7626	8026	9026	10626
0-9 5/16 (237)					

2-0 AND 2-6 HEIGHTS:		
	2-0 Height	2-6 Height
Clad MO (mm)	2-0 1/4 (616)	2-6 1/4 (768)
Wood MO (mm)	2-2 1/4 (667)	2-8 1/4 (819)
RO (mm)	2-0 1/2 (622)	2-6 1/2 (775)
FS (mm)	2-0 (610)	2-6 (762)
DLO (mm)	1-3 5/16 (389)	1-9 5/16 (541)

NOTES:

- Some transoms available factory mullled.
- For stand alone wood units in masonry openings add 11/16" (17) to the masonry opening height only.
- Please contact your local Marvin® representative for information on structural mulling guidelines.
- Please contact your local Marvin representative for masonry openings that include casings and subsills.


Clad Ultimate Inswing French Door Transoms: **CUIFDT**
 Clad Ultimate Outswing French Door Transoms: **CUOFDT**
 Wood Ultimate Inswing French Door Transoms: **WUIFDT**
 Wood Ultimate Outswing French Door Transoms: **WUOFDT**

1 3/4" ULTIMATE SWINGING FRENCH DOOR TRANSOMS


1 FRAME 4 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

Clad MO (mm)	7-11 1/2 (2426)	9-11 1/2 (3035)	10-7 1/2 (3239)	11-11 1/2 (3645)	13-11 1/2 (4255)
Wood MO (mm)	8-2 1/8 (2492)	10-2 1/8 (3102)	10-10 1/8 (3305)	12-2 1/8 (3712)	14-2 1/8 (4321)
RO (mm)	8-0 (2438)	10-0 (3048)	10-8 (3251)	12-0 (3658)	14-0 (4267)
FS (mm)	7-11 (2413)	9-11 (3023)	10-7 (3226)	11-11 (3632)	13-11 (4242)
DLO (mm)	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)


1-6 1/4 (464)
1-8 1/4 (514)
1-6 1/2 (470)
1-6 (457)
0-9 5/16 (237)




8016
8020
8026




10016
10020
10026



10816
10820
10826



12016
12020
12026



14016
14020
14026

NOTES:

- Some transoms available factory mullled.
- For stand alone wood units in masonry openings add 11/16" (17) to the masonry opening height only.
- Please contact your local Marvin® representative for information on structural mulling guidelines.
- Please contact your local Marvin representative for masonry openings that include casings and subsills.

2-0 AND 2-6 HEIGHTS:		
	2-0 Height	2-6 Height
Clad MO (mm)	2-0 1/4 (616)	2-6 1/4 (768)
Wood MO (mm)	2-2 1/4 (667)	2-8 1/4 (819)
RO (mm)	2-0 1/2 (622)	2-6 1/2 (775)
FS (mm)	2-0 (610)	2-6 (762)
DLO (mm)	1-3 5/16 (389)	1-9 5/16 (541)