

Commercial Door and 2 1/4" Door Panel Sweep Field Applied Installation Instruction

Attention Installer:

Marvin Windows and Doors recommends that the enclosed panel sweep be applied *after* the unit has been properly installed to allow for proper fit between the sweep and sill.

NOTE: Numbers listed in parentheses () are metric equivalents in millimeters rounded to the nearest whole number.

1. Align the sweep to edge of panel.
2. With the pre-drilled holes in the sweep as your guide, use 7/64" (3) bit to drill pilot holes approximately 3/4" (19) deep.
3. Attach sweep using the provided screws. For clad units use #6 x 1/4" screws and tighten by hand with a screwdriver. For wood units use the #6 x 1 1/4" screws. **Do not over tighten.**

4. Only commercial products will have weatherstrip applied.
5. Operate panel to check for proper contact.

