

WOOD ULTIMATE DOUBLE HUNG

MO (mm)	2-0 1/2 (622)	2-4 1/2 (724)	2-8 1/2 (826)	2-10 1/2 (876)	3-0 1/2 (927)	3-2 1/2 (978)	3-4 1/2 (1029)	3-8 1/2 (1130)	4-0 1/2 (1232)
RO (mm)	1-10 3/8 (568)	2-2 3/8 (670)	2-6 3/8 (772)	2-8 3/8 (822)	2-10 3/8 (873)	3-0 3/8 (924)	3-2 3/8 (975)	3-6 3/8 (1076)	3-10 3/8 (1178)
FS (mm)	1-9 3/8 (543)	2-1 3/8 (645)	2-5 3/8 (746)	2-7 3/8 (797)	2-9 3/8 (848)	2-11 3/8 (899)	3-1 3/8 (949)	3-5 3/8 (1051)	3-9 3/8 (1153)
DLO (mm)	1-2 15/16 (379)	1-6 15/16 (481)	1-10 15/16 (583)	2-0 15/16 (633)	2-2 15/16 (684)	2-4 15/16 (735)	2-6 15/16 (786)	2-10 15/16 (887)	3-2 15/16 (989)

2-10 9/16 (878) 2-9 1/2 (851) 2-9 (838) 0-1 15/16 (278)									
3-2 9/16 (980) 3-1 1/2 (953) 3-1 (940) 1-0 15/16 (329)									
3-6 9/16 (1081) 3-5 1/2 (1054) 3-5 (1041) 1-2 15/16 (379)									
3-10 9/16 (1183) 3-9 1/2 (1156) 3-9 (1143) 1-4 15/16 (430)									
4-2 9/16 (1284) 4-1 1/2 (1257) 4-1 (1245) 1-6 15/16 (481)									
4-6 9/16 (1386) 4-5 1/2 (1359) 4-5 (1346) 1-8 15/16 (532)									
4-10 9/16 (1488) 4-9 1/2 (1461) 4-9 (1448) 1-10 15/16 (583)									
5-2 9/16 (1589) 5-1 1/2 (1562) 5-1 (1549) 2-0 15/16 (633)									
5-6 9/16 (1691) 5-5 1/2 (1664) 5-5 (1651) 2-2 15/16 (684)									

MULTIPLE ASSEMBLY CONVERSIONS

ROUGH OPENING		MASONRY OPENING WITH BMC	
Width	Height	Width	Height
Add all frame sizes plus 1" (25)	Add frame sizes plus 1/2" (13)	Add all frame sizes plus 3 1/8" (79)	Add frame sizes plus 1 9/16" (39)

NOTES:

E These windows meet national egress codes for fire evacuation. Local codes may differ.
* For more Cottage Style sizes than the sample shown, please contact your Marvin® representative.

* Ultimate Double Hung cottage call number formula is figured in fifths.

- Top sash is 2/5 and bottom is 3/5
 - 1. Standard call number; 2024
 - 2. Add the two glass heights; 24" + 24" = 48"
 - 3. Divide 48" by 2/5; 19-13/64"
 - 4. Round to the nearest standard glass height; 20"
 - 5. Subtract from total glass height; 48" - 20" = 28"
- The call number for the above example is: 2020/28
The top sash will be a 2020 and the bottom sash will be a 2028

Wood Ultimate Double Hung: **WUDH**
NOT TO SCALE

WOOD ULTIMATE DOUBLE HUNG UNIT

MO (mm)	2-0 1/2 (622)	2-4 1/2 (724)	2-8 1/2 (826)	2-10 1/2 (876)	3-0 1/2 (927)	3-2 1/2 (978)	3-4 1/2 (1029)	3-8 1/2 (1130)	4-0 1/2 (1232)
RO (mm)	1-10 3/8 (568)	2-2 3/8 (670)	2-6 3/8 (772)	2-8 3/8 (822)	2-10 3/8 (873)	3-0 3/8 (924)	3-2 3/8 (975)	3-6 3/8 (1076)	3-10 3/8 (1178)
FS (mm)	1-9 3/8 (543)	2-1 3/8 (645)	2-5 3/8 (746)	2-7 3/8 (797)	2-9 3/8 (848)	2-11 3/8 (899)	3-1 3/8 (949)	3-5 3/8 (1051)	3-9 3/8 (1153)
DLO (mm)	1-2 15/16 (379)	1-6 15/16 (481)	1-10 15/16 (583)	2-0 15/16 (633)	2-2 15/16 (684)	2-4 15/16 (735)	2-6 15/16 (786)	2-10 15/16 (887)	3-2 15/16 (989)

5-10 9/16 (1792) 5-9 1/2 (1765) 5-9 (1753) 2-4 15/16 (735)									
6-2 9/16 (1894) 6-1 1/2 (1867) 6-1 (1854) 2-6 15/16 (786)									
6-6 9/16 (1996) 6-5 1/2 (1969) 6-5 (1956) 2-8 15/16 (837)									
6-10 9/16 (2097) 6-9 1/2 (2070) 6-9 (2057) 2-10 15/16 (887)									
7-4 9/16 (2200) 7-3 1/2 (2173) 7-3 (2161) 3-2 15/16 (989)									
7-8 9/16 (2302) 7-7 1/2 (2275) 7-7 (2262) 3-4 15/16 (1040)									

COTTAGE STYLE*

MO (mm)	2-0 1/2 (622)	2-4 1/2 (724)	2-8 1/2 (826)	2-10 1/2 (876)	3-0 1/2 (927)	3-2 1/2 (978)	3-4 1/2 (1029)	3-8 1/2 (1130)	4-0 1/2 (1232)
RO (mm)	1-10 3/8 (568)	2-2 3/8 (670)	2-6 3/8 (772)	2-8 3/8 (822)	2-10 3/8 (873)	3-0 3/8 (924)	3-2 3/8 (975)	3-6 3/8 (1076)	3-10 3/8 (1178)
FS (mm)	1-9 3/8 (543)	2-1 3/8 (645)	2-5 3/8 (746)	2-7 3/8 (797)	2-9 3/8 (848)	2-11 3/8 (899)	3-1 3/8 (949)	3-5 3/8 (1051)	3-9 3/8 (1153)
DLO (mm)	1-2 15/16 (379)	1-6 15/16 (481)	1-10 15/16 (583)	2-0 15/16 (633)	2-2 15/16 (684)	2-4 15/16 (735)	2-6 15/16 (786)	2-10 15/16 (887)	3-2 15/16 (989)

5-10 9/16 (1792) 5-9 1/2 (1765) 5-9 (1753) 1-10 15/16 (583) / 2-10 15/16 (887)									
--	--	--	--	--	--	--	--	--	--