Marvin French Door Wood Sill Overlay Supplemental Instruction



ABSTRACT: Mahogany sill covers are available for Clad Inswing and Wood Inswing French Door units with X and XX configurations.

Installing the Sill Cover

1. Remove the tape backing from the tape that is applied to the back of the cover. There is one strip on a 4 9/16" cover and two strips on a 6 9/16" cover. See figure 1.



Figure 1

2. Align notch on cover to the screen track on the sill. See figure 2.




Figure 2

3. Press in place. See figure 3.



Figure 3

4. Finish as desired.